Emergency Response Plan

For

AK2-13239

Revision Number: | Original

Completed by: Crystal McDonald

Phone Number: (907) 562-2929

E-mail: pmsi@gci.net

Date: February 11, 2014

Table of Contents

I. System Specific Information	1
II. Internal Chain of Command	6
III. External Communication	7
IV. Example Health Advisories	10
V. Personnel Safety	14
VI. Alternate Water Sources	15
VII. Property Protection	16
VIII. Water Sampling and Monitoring	17
IX. Plan Revisions, Evaluation and Exercises	21
X. Plan Appendix Documents	23

I. System Specific Information

System Contact Information

AK213239 **PWS-ID Number:** System Name: Bear Mountain Condo Association PWS Type Class A (community Population Served: 65 2 Number of Connections: PWS Contact Name: Crystal McDonald, Property Management Services, Inc Title of Contact Person: Manager Contact Address: 601 W 41st Avenue, Suite 201 City, Zip: Anchorage, 99504 Contact Phone: (907) 562-2929 Contact Fax: (907) 562-3550

Emergency Contact Information

ER Lead: Ryan Rhodes **Utility Title: Association Board Member** Daytime Phone: 907-952-2395 Evening Phone: 907-952-2395 Cell Phone: 907-952-2395 Fax Number: NA Pager Number: NA Email: NA

Alternate ER Lead: Property Management Services, Inc (PMSI) Utility Title: **Association Manager** Daytime Phone: 907-562-2929 Evening Phone: 907-562-2929 907-229-5313 (Crystal McDonald) Cell Phone: 907-562-3550 Fax Number: NA Pager Number: Email: pmsi@gci.net


Person Responsible for	Developing and Maintaining ERP				
Employee Completing Plan:	Crystal McDonald, Property Management Services, Inc				
Title:					
	Manager				
Phone Number:	(907) 562-2929				
Outside Assisting Technician:	NA				
Phone Number:	NA				
Date of Plan:	February 24, 2014				
System Information – D	rinking Water Source, Pumping, Treatment				
Water Source = Groundwater					
Location	: 22717 Sherman Street, Chugiak, AK 99567				
Depth/Description	:				
Well Service Company	Arctic Pump & Well Services				
Contact Phone	: 907-688-2510				
Well Pump Mfr.	Zurac & Clayton				
Well Pump Model					
Location	:				
Pump Service Company	: Arctic Pump & Well Services				
Contact Phone	: 907-688-2510				
Surface Water Source	: N/A				
Location					
Description					
Pump Mfr.					
Pump Model					
Pump Service Company					
Contact Phone					
Contact I none					
Transmission Line Pipe Type					
Pipe Size / Diameter	: 1 1/4"				

Treatment System Component Location:	n/a at this time all treatment is localized at service points
Description:	
Mfr./Model Number:	
Service Company:	
Contact Phone:	
Repair and/or Vendor(s):	
Contact Phone:	
System Information – Fin	ished Water Storage, Distribution and Valves
Finished Water Tank of ClearWell	
Location	:
Capacity/Description	:
Mfr./Model Number	:
Service Company	:
Contact Phone	:
Distribution System Description	
Type of Pipe	: Galvanized steel
Size/Diameter	: 1 1/4"
Length	: Approximately 3000-ft
Pipe Vendor	:
Contact Phone	:
Describe Hydrant/Appurtenance Locations	
Type of Hydrant	:
Number of Hydrant Type	:
Size of Hydrant	:
Number of Hydrant Size	:
Vendor	:
Contact Phone	:

Describe Valve Locations	:
Valve Type/Mfr.	:
Number of Valve Type/Mfr.	
Valve Size	:
Number of Valve Size	:
Vendor	:
Contact Phone	:
System Information – Inf	rastructure
Building #1:	Well Head (no structure)
Location:	22717 Sherman Street, Chugiak, AK 99567
Building Maintenance Contact:	R&S Plumbing
Use/Description/Type:	
Electrical Power Source:	Hard wired
Contact Name:	Matanuska Electric Association
Contact Number:	907-761-9500
Anniliamy Danyam Canmaa	N/A
Auxiliary Power Source:	IV/A
Location/Description: Mfr/Model Number:	
Service Company:	
Contact Phone:	
Location of Site Plans and Facility "As-Built" Engineering Drawings:	The limited drawings currently are housed via pdf at the offices of PMSI, 601 W 41 st Avenue, Suite 201, Anchorage, 99502
Operating Procedures and System Descriptions, O&M manual (including back-up systems):	On-site and on file with management office

Location and Type of Maintenance Supplies and/or parts:	N/A
System Information – Cri	tical Customers
Name/Organization:	
Location:	
Contact Name:	
Contact Number:	
System Information – Add	ditional Information

II. Internal Chain of Command



Internal Notification List

Order	Name	Emergency Title	Home Phone	Work Phone	Cell, pager or email
1.	Crystal McDonald	Emergency Lead	562-2929		229-5313
2	Mitch Eaton	Emergency Lead2	562-2929		394-5517
3.	Ryan Rhodes	Alternate Emergency Lead	952-2395		
4.	Kerry Nesmith	Media Spokesperson	230-1538		
5.	Arctic Pump & Well	Operator	688-2510		
6.	R&S Plumbing	Operator	694-6646		
7.	PMSI	Public Works Manager/Director	562-2929		

III. External Communication

Title	Phone Number	Alternate Contact			
Police	911				
Fire	911				
EMS	911				
Alaska State Troopers	(907) 269-5511				
DEC Drinking Water Program	(907)269-7616				
Clinic or Hospital:					
Local Public Health Department	(907) 343-6718	Health and Human Service			
Mayor's Office	(907) 343-7100				
Regional Health Corporation	N/A				
Critical Customer:	N/A				
State Emergency Coordination Center	1-888-462-7100				
Alaska FBI Terrorism Contact	276-4441				
State HAZMAT Team	1-800-478-9300				
Remote Maintenance					
Worker:					
Heavy Equipment					
Operator:					
Laboratory/Water	Forest Taylor,	Forest.taylor@sgs.com			
Testing:	SGS	,			
Well/Pump Service	(007) 257 1200				
Newspaper:	(907) 257-4200	Anchorage Daily News			

Current Equipment or Process	Model Number or Description	Type of Spare Parts on hand	Primary Manufactu rer or Supplier	Contact Phone	Alternate supplier	Contact Phone
Well pump						
Pump repair kit						
Treatment pump						
Chlorinator						
Chlorination meter						
Chlorine						
Ozone						
Ozonator						
Ozonation meter						
Filtration string						
Filters						
Turbidity meter						
SCADA						
Auxiliary power						
Process chemicals						
Valves						
Distribution line						
Repair parts						

Media Plan

	Kerry Nesmith, 230-1538
Our designated utility media spokesperson is:	
Basic fact sheets and sample heath advisories are located:	All information is available on the utilities website located at www.pmsialaska.com , to include CCRs and updates on construction.
Our notification plan for delivering messages (such as public health advisories) includes the following distribution methods:	Local postings in the event of emergencies Mass mail outs Notices on the website

Public and Media Communications Strategies

- Any decision to issue a public notification should be made in consultation with the State Drinking Water Program. You also should make arrangements with your local health department and/or other appropriate organizations prior to a major event in order to establish clear lines of communication.
- In your press release or notice you should explain to the media what information you are trying to communicate and why. The most important information, including a description of the situation, populations at risk, instructions to consumers, and potential health effects, should be near the beginning of any press release or notice. Be sure to include a contact name and telephone number so that the media can call you for more information. Remember to avoid technical or confusing language in your press releases and notices.

General Tips on Working with the Media

- Be truthful and up-front.
- Answer questions as well as you can, but don't be afraid to say that you need to check on something if there is a question you can't answer (once you find the information, quickly report back on what you've found).
- Be sensitive to the fact that reporters may be working on tight deadlines.
- Provide a list of the elements that should be addressed.
- Don't be upset if a newspaper article or news report isn't exactly as you would want it, but politely tell a reporter if a significant piece of information is wrong or missing.
- Don't be defensive when answering questions.

IV. Example Health Advisories

(Note: These must be customized and completed prior to use)

DRINKING WATER WARNING

Bear Mountain Water System water is contaminated with [fecal coliform] or [*E. coli*]

BOIL YOUR WATER BEFORE USING

Fecal coliform [or *E. coli*] bacteria were found in the water supply on <u>INSERT DATE HERE</u>. These bacteria can make you sick, and are a particular concern for people with weakened immune systems.

What should I do?

- DO NOT DRINK THE WATER WITHOUT BOILING IT FIRST. Bring all water to a boil, let it boil for one minute, and let it cool before using, or use bottled water. Boiled or bottled water should be used for drinking, making ice, brushing teeth, washing dishes, and food preparation until further notice. Boiling kills bacteria and other organisms in the water.
- Fecal coliforms and E. coli are bacteria whose presence indicates that the water may be contaminated with human or animal wastes. Microbes in these wastes can cause diarrhea, cramps, nausea, headaches, or other symptoms. They may pose a special health risk for infants, young children, some of the elderly, and people with severely compromised immune systems.
- If you experience any of these symptoms and they persist, you may want to seek medical advice. People at increased risk should seek advice about drinking water from their health care providers.

What happened? What is being done?

Bacterial contamination can occur when increased run-off enters the drinking water source (for example, following heavy rains). It can also happen due to a break in the distribution system (pipes) or a failure in the water treatment process.

<u>DESCRIBE CORRECTIVE ACTION HERE</u> We will inform you when tests show no bacteria and you no longer need to boil your water. We anticipate resolving the problem within <u>ESTIMATED TIME FRAME</u>.

For more information, please contact Crystal McDonald at (907) 562-2929 or P.O. Box 92130, Anchorage, AK 99509-2130. General guidelines on ways to lessen the risk of infection by microbes are available from the EPA Safe Drinking Water Hotline at 1(800) 426-4791.

Please share this information with all the other people who drink this water, especially those who may not have received this notice directly (for example, people in apartments, nursing homes, schools, and businesses). You can do this by posting this notice in a public place or distributing copies by hand or mail.

This notice is being sent to you by Bear Mountain Condo Association State Water System ID#: AK213239. Date distributed:

DRINKING WATER WARNING

BOIL YOUR WATER BEFORE USING

Disease-causing organisms have entered Bear Mountain Condo Association water supply.

These organisms are causing illness in people served by Bear Mountain Condo Association. We learned of a waterborne disease outbreak from INSERT AGENCY HERE on INSERT DATE HERE.

What should I do?

- DO NOT DRINK THE WATER WITHOUT BOILING IT FIRST. Bring all water to a boil, let it boil for one minute, and let it cool before using, or use bottled water. Boiled or bottled water should be used for drinking, making ice, brushing teeth, washing dishes, food preparation and bathing until further notice. Boiling kills bacteria and other organisms in the water.
- DESCRIBE SYMPTOMS OF THE WATERBORNE DISEASE HERE If you experience one or more
 of these symptoms and they persist, contact your doctor. People with severely compromised
 immune systems, infants, and some elderly may be at increased risk. These people should seek
 advice about drinking water from their health care providers.

What happened? What is being done?

DESCRIBE THE OUTBREAK, CORRECTIVE ACTION, AND WHEN THE OUTBREAK MIGHT END HERE.

We will inform you when you no longer need to boil your water.

For more information, please contact Crystal McDonald at (907) 562-2929 or P.O. Box 92130, Anchorage, AK 99509-2130. General guidelines on ways to lessen the risk of infection by microbes are available from the EPA Safe Drinking Water Hotline at 1(800) 426-4791.

Please share this information with all the other people who drink this water, especially those who may not have received this notice directly (for example, people in apartments, nursing homes, schools, and businesses). You can do this by posting this notice in a public place or distributing copies by hand or mail.

This notice is being sent to you by Bear Mountain Condo Association State Water System ID#: AK213239. Date distributed:

WARNING DO NOT DRINK THE WATER

CONTAMINANT NAME found in the Bear Mountain Condo Association water supply on DATE

on DATE
Bottled water can be obtained at,24 hours per day.
What should I do?
 Do NOT drink the water. Symptoms associated withare, If you or someone you know exhibits any of these symptoms, immediately contact your health care provider. In addition, please notify the public health department at 343-4677.

What happened? What is being done?

SAMPLE NARRATIVE: On October 10th, the water distribution system was contaminated with cyanide. We are working with law enforcement and the public health department to investigate/resolve this issue. We have tested the water invarious parts of the distribution system to verify the extent of the cyanice contamination. Based on these tests, we have isolated the portion of the system located north of Aspen Street and east of River Road. Everyone in this portion of the system should not drink the water. We have implemented additional security procedures to protect the system against further contamination. Additional information will be provided 24 hours/day on Channel 57-the local government television channel.

For more information, please contact Crystal McDonald at (907) 562-2929 or P.O. Box 92130, Anchorage, AK 99509-2130. General guidelines on ways to lessen the risk of infection by microbes are available from the EPA Safe Drinking Water Hotline at 1(800) 426-4791.

Please share this information with all the other people who drink this water, especially those who may not have received this notice directly (for example, people in apartments, nursing homes, schools, and businesses). You can do this by posting this notice in a public place or distributing copies by hand or mail.

This notice is being sent to you by Bear Mountain Condo Association State Water System ID#: AK213239. Date distributed:

V. Personnel Safety

Emergency Response and Safety Plan

The evacuation plan for this facility is located:	Well head
The evacuation leader is (name):	Ryan Rhodes
The assembly area is (location):	22717 Sherman Street
The designated safety officer is (name):	Kerry Nesmith
The written safety and health plan is located:	On-site and on file with management office
The MSDS book is located:	
Other safety plan documents are located:	Distributed to each resident
First Aid	
The first-aid kit for this facility is located:	In on-site office
Our first-aid/CPR trained personnel are (names):	None
Personal Protective Equip	ment
	None
Emergency response PPE for this facility includes:	
	None
PPE is located:	

VI. Alternate Water Sources

Alternate Water Sources

			nent			Type of Usage	
Name/ Description – Type of Source (e.g. lake, well, water hauler, bottled water)	Location	Contact Name & Phone	Written Mutual Aid Agreement in Place?	Long-term	Short-term	DEC Approved Drinking Water	Non-DEC Approved for other uses

VII. Property Protection

Property Protection and Security

Our procedure for "lock down" or access control:	Pumps are turned off
The person responsible for establishing a security perimeter during an event is (name):	Anchorage Police Department Anchorage Fire Department
Our procedure for evidence protection (if the event is a crime) is:	Anchorage Police Department Anchorage Fire Department
Other property protection procedures and measures in place are:	None

VIII. Water Sampling and Monitoring

Standard Treatment and Monitoring - Plans

Our monitoring plan location is:	Property Management Services, Inc
The person responsible for	Arctic Pump & Well
routine monitoring is:	
Our emergency sample	On-site office
collection kit is located:	

Standard Treatment and Monitoring – Testing/Analysis

Analysis	Frequency	Laboratory (or in- house lab)		
Arsenic	Yearly	SGS	PMSI	562-2929

Laboratory Contact List

Analysis	Laboratory	Physical Address	Contact Person	Phone
Pathogens				
Chemical				
Radiological				
Chemical Warfare or WMD Agents	National Response Center			1-800-424-8802
Chemical Warfare or WMD Agents	National Response Center	Seattle Office	24-hour Duty Officer	1-206-553-1263

Recommended Emergency Water Sample Collection Kit

Item	Quantity	Notes	Qty
Field Resources and Documentation			
Field guide	2	Resource for field personnel	
Health and safety plan	2	If required for the site	
Chain of custody forms	24	For documenting sample custody	
Lab marker	2	Waterproof, 1 red, 1 black	
General Sampling Supplies			•
Sample containers	various	For collecting samples	
Device for grab sampling	1	For sampling large water bodies	
10 liter HDPE container	4	For collection of large volume water samples	
Collapsible cooler	1	For sample storage	
Rigid shipping container	1	For shipping by overnight service if needed.	
1 qt. zippered freezer bags	1 pack100	For double bagging ice and sample containers	
Paper towels	2 rolls	Wiping wet containers and containing spills	
Safety Supplies	1	, , , , , , , , , , , , , , , , , , , ,	1
Splash resistant goggles	2	One per individual (minimum)	
Disposable gloves	6 pairs	Nitrile or polyethylene, powder-free	
Disposable shoe covers	2 pairs	One pair per individual (minimum)	
Disposable laboratory coats	2	One per individual (minimum)	
Clear, heavy duty plastic trash bags	4	For disposal of lab coat, gloves, etc.	
Rinse water	20 liters	For general use and first aid	
Antiseptic wipes	1 pkg	For cleaning hands, sample containers, etc.	
Bleach solution (at least 5%)	1 gallon	For decontamination if necessary	
Squirt bottle	2	For use with rinse water or lab grade water	
First aid kit	1	For general first aid	
Flashlight/headlamp	3	For working at night or in dark locations	
Respirator	2	As required, if respiratory program in place	
Respirator cartridges	Assorted	Organic Vapor, HEPA, Chlorine, as required	
		organization of the state of th	
			+
	1		

Sample Collection Guidelines

Safety Guidelines

- 1. Do not enter the site to perform sampling until cleared. Hazardous materials response units may perform safety screening before allowing other responders to enter the site. Note that field safety screening does not generally include testing for pathogens.
- 2. Do not eat, drink, or smoke at the site.
- 3. Do not taste or smell the water samples.
- 4. Do use general personal protective equipment (PPE) such as splash-proof goggles, disposable gloves, proper footwear (i.e., no open toe or open heel shoes), a chemical resistant, disposable lab coat, and long pants. (Note that this level of PPE is only intended to minimize incidental contact with the water or chemical reagents used during sample collection or field testing.)
- 5. Avoid all skin contact with the water, and if incidental contact does occur, immediately flush the affected area with clean water brought to the site for that purpose.
- 6. Fill sampling containers slowly to avoid volatilization or aerosolization of contaminants.
- 7. Minimize the time that personnel are on the site and collecting samples.

Sampling Procedures

- 1. Pre-label sample containers with a waterproof marker. Information should include: analyte class (pathogen, chemical, or radionuclide), specific analyte (if sample is being collected for a specific target), sample identification number, utility name, location of sample collection, sample collection date and time, and sampler's initials.
- 2. Check for the presence of any in-line filters (e.g., home treatment devices) that might interfere with sampling. Remove such devices if present.
- 3. If the sample tap is the suspected point of contaminant introduction, collect swab samples from the tap before flushing the tap and collecting water samples.
- 4. Flush sample taps for a time sufficient to displace the water in connecting lines in order to obtain a sample that is representative of the water of interest. Keep the flow rate from the sample tap sufficiently low in order to avoid splashing and aerosolizing water droplets. Divert water to a drain if possible.
- 5. Carefully collect samples in the specified containers (see Section 3.3 of the "EPA Response Guidelines" available on the Resources page). If a reagent needs to be added to the sample, allow enough headspace in the container to add the proper amount of preservative. Cap then gently mix the contents to ensure that the reagent is properly mixed with the sample. Test the sample with a strip of pH paper to ensure preservation to the proper pH. Do not insert the pH paper into the sample container. Pour a small portion of the mixed sample into the container cap then pour from the cap onto the pH paper to verify
- 6. For chlorinated samples, VOCs should be collected into a secondary 8-oz. glass container (prepared with ascorbic acid see footnote 1, Table 3.3 of the "EPA Response Guidelines" available on the Resources page). Gently mix the sample and transfer to 3, 40-ml VOA containers (triplicate). Fill the 40-ml container above the top to form a meniscus. Close the container with the Teflon side of the septa facing the water sample, gently invert the sample container several times, and verify that there are no air bubbles in the container. Once each container is tagged, the three 40-ml containers should be inserted into a plastic whirlpack bag (provided) and sealed prior to sample storage.
- 7. Wipe the outside of the sealed containers with paper towel.
- 8. Attach custody seal to the sample container.

- 9. Place the sealed container into a rigid cooler and pack with frozen ice packs (preferred) or sealable freezer bags filled with ice.
- 10. Tag each sample and record all necessary information on "Sample Documentation" and "Chain of Custody" forms.
- 11. After all samples have been collected, preservative blanks and temperature blanks should be prepared and tagged. A preservative blank should be prepared for each preservative used during the sampling event. The preservative blank can be prepared by adding the appropriate amount of preservative to the preservative blank containers, and tagging the sample for the appropriate analysis (i.e., HNO3 preservative blank should be analyzed for metals). Additionally, a temperature blank container should be placed in each cooler containing samples.

Sample Holding

- 1. When samples are not in the possession of designated personnel, they should be secured (e.g., locked in a secure area) and only accessible by designated personnel. In the field, samples may need to be locked in a vehicle.
- 2. Samples should be chilled, but protected from freezing.
- 3. Samples should be held at the drinking water utility lab until shipped to a lab for analysis or until it is determined that they are not needed.
- 4. Samples that are held longer than the approved holding times for contaminant analysis may no longer be useful.

Sample Transport

- 1. Sample integrity and chain of custody must be maintained. All factors that might compromise sample integrity (e.g., storage containers, excessive transit time, temperature, pressure, physical disturbance, etc.) should be considered and appropriate measures taken to avoid compromising samples.
- 2. Sample packaging must be in compliance with shipping regulations.
- 3. Samples may be screened by law enforcement and/or ICs prior to sample transport to the laboratory.
- 4. Samples will be transported to the appropriate laboratory in coordination with law enforcement using appropriate air and ground assets.

IX. Plan Revisions, Evaluation and Exercises

Plan Revision History

Change Number	Subject/ Description of Change	Date	Entered by:	

Plan Evaluation History

Date	Description of Evaluation Activities	Participants

Plan Exercise and Training Records

Date	Description of Exercise or Training Event	Participants	

X. Plan Appendix Documents

dditional Documents Attached:						